Basis via condensator met massa verbonden Ingang is de emitter; uitgang via collector

Spanningsversterking (voltage gain)


$$A_v = \frac{V_c}{V_e} = \frac{I_c(R_{\text{C}} \| R_L)}{I_e(r_e' \| R_{\text{E}})}$$

$$A_{v} = \frac{R_{C} || R_{L}}{r'_{e} || R_{E}}$$

(I<sub>c</sub> is ongeveer even groot als I<sub>e</sub>)


$$A_v \cong \frac{R_c}{r'_c}$$

(vereenvoudiging als r'e heel wat kleiner is dan R<sub>E</sub> )



(a) Typical common-base (CB) amplifier

#### FIGURE 3-42





## Spanningsversterking met een verzadigings (swamping) weerstand

Doel: vervorming voorkomen door te kleine  $r'_{e}$  waarde => kleine weerstand  $R_{E1}$  in de schakeling aanbrengen (= swamping resistor)

$$A_{\nu} \simeq \frac{R_{\rm C} \| R_L}{r_e' + R_{\rm E1}}$$




FIGURE 3-43 CB amplifier with swamping resistor.

## Ingangsweerstand (blz. 149)


 $R_E$  staat parallel met  $r'_e \Rightarrow R_{in(tot)}$  is ongeveer gelijk aan  $r'_e$ 

Met swampingweerstand:

$$R_{in(tot)} \cong r'_e + R_{E1}$$


## Uitgangsweerstand

Uitgangscircuit common base is hetzelfde als deze van een common emittor =>  $R_{out} = R_{C}$ 



(a) Typical common-base (CB) amplifier

#### FIGURE 3-42



#### EXAMPLE 3-14

Find the total input resistance and the voltage gain for the CB amplifier in Figure 3-43.

#### SOLUTION

In order to determine  $r'_e$ , it is first necessary to find  $I_E$ . Find the dc voltage on the base using the voltage-divider rule.

$$V_{\rm B} = \left(\frac{R_2}{R_1 + R_2}\right) V_{\rm CC} = \left(\frac{15 \,\mathrm{k}\Omega}{36 \,\mathrm{k}\Omega + 15 \,\mathrm{k}\Omega}\right) 15 \,\mathrm{V} = 4.41 \,\mathrm{V}$$

The emitter voltage is one diode drop less than the base.

$$V_{\rm E} = V_{\rm B} - V_{\rm BE} = 4.41 \, \text{V} - 0.7 \, \text{V} = 3.71 \, \text{V}$$

From Ohm's law, the emitter current is

$$I_{\rm E} = \frac{V_{\rm E}}{R_{\rm E}} = \frac{3.71 \text{ V}}{1.53 \text{ k}\Omega} = 2.43 \text{ mA}$$

The value of  $r'_e$  can now be found.

$$r'_e = \frac{25 \text{ mV}}{I_E} = \frac{25 \text{ mV}}{2.43 \text{ mA}} = 10.3 \Omega$$




FIGURE 3-43 CB amplifier with swamping resistor.

Looking from the input coupling capacitor, the total input resistance is the sum of the swamping resistor and  $r'_e$ .

$$R_{in(tot)} = r'_e + R_{E1} = 10.3 \Omega + 27 \Omega = 37.3 \Omega$$

The signal voltage gain is the ratio of the collector ac resistance to the emitter ac resistance. The collector ac resistance,  $R_c$ , is equal to  $R_C \parallel R_L$ . The emitter ac resistance is equal to  $r'_e + R_{E1}$ . Therefore, the voltage gain is

$$A_{v} \cong \frac{R_{c}}{R_{e}} = \frac{R_{C} \| R_{L}}{r'_{e} + R_{E1}} = \frac{3.6 \text{ k}\Omega \| 3.6 \text{ k}\Omega}{10.3 \Omega + 27 \Omega} = 48$$

## EXAMPLE 3-15

Find the total input resistance and voltage gain for the CB amplifier in Figure 3-44.

### SOLUTION

Since the base is grounded, the emitter voltage is 0.7 V above ground. It can be shown with an equation as

$$V_{\rm E} = V_{\rm B} - V_{\rm BE} = 0 \, \text{V} - (-0.7 \, \text{V}) = +0.7 \, \text{V}$$

Applying Ohm's law for the emitter current,

$$I_{\rm E} = \frac{V_{R_{\rm E}}}{R_{\rm E}} = \frac{V_{\rm EE} - V_{\rm E}}{R_{\rm E}} = \frac{15 \text{ V} - 0.7 \text{ V}}{10 \text{ k}\Omega} = 1.43 \text{ mA}$$

The value of  $r'_e$  is

$$r'_e = \frac{25 \text{ mV}}{I_E} = \frac{25 \text{ mV}}{1.43 \text{ mA}} = 17.5 \Omega$$

Since there is no swamping resistor, the total input resistance (looking from the input coupling capacitor) is just  $r'_e$ . Therefore, the total input resistance is

$$R_{in(tot)} = r'_e = 17.5 \Omega$$

The signal voltage gain, measured from the input coupling capacitor to the load resistor, is

$$A_v \equiv \frac{R_c}{R_e} \equiv \frac{R_C \| R_L}{r_e'} = \frac{5.6 \,\mathrm{k}\Omega \| 10 \,\mathrm{k}\Omega}{17.5 \,\Omega} = 205$$






FIGURE 3-44




## Meest voorkomende toepassingen GBS

 Lage ingangsimpedantie is een goede keuze om het signaal van een microfoon, gebaseerd op het principe van een bewegende spoel, te versterken.

 De lage ingangsweerstand van de GBS zorgt er voor dat er zoveel mogelijk vermogen van de microfoon wordt overgedragen naar de versterker (maximaal als de uitgangsweerstand van de microfoon gelijk is aan de ingangsweerstand van de GBS-versterker.

• Versterkers met een lage ingangsweerstand hebben een betere ruisimmuniteit dat versterkers met een hoge ingangsweerstand.



• Bij VHF- en UHF-systemen helpt de aan massa aangesloten basis de emitter te isoleren van de collector. Hierdoor is er zeer weinig terugkoppeling vanuit de collector naar de emiiter waardoor de kans op oscillaties bij GBS-versterkers kleiner is dan bij GES-versterkers. (Doordat de emiter als ingang wordt gebruikt is de invloed van de interne junctiecapaciteiten van de transistor kleiner dan bij de GES-versterker. Deze interne junctiecapaciteiten begrenzen de frequentieresponse van de inverterende versterkers zoals GES-versterkers



Samenvatting AC-parameters voor CE, CC en CB versterkers (blz. 151)

# TABLE 3-2 • Comparison of amplifier ac parameters. Voltage-divider bias is assumed for all amplifiers with an unbypassed emitter resistor in the CE and CB configurations.

	CE	CC	СВ
Voltage gain	$A_v \simeq -\frac{R_c}{R_c}$	$A_{\nu} \equiv 1$	$A_v \equiv \frac{R_c}{R_c}$
	High	Low	High
Input resistance	$R_{in(tot)} = R_1   R_2   [\beta_{ac}(r'_c + R_{E1})]$ Low	$R_{in(tot)} = R_1 \  R_2 [\beta_{ac}(r'_e + R_E \  R_L)]$ High	$R_{in(tot)} = r'_e + R_{E1}$ Very low
Output resistance	R <sub>C</sub> High	$\cong r'_e$ Low	R <sub>C</sub> High



## **Section 3-6 CHECKUP**

- 1. Kan dezelfde spanningsversterking bekomen worden met een GBS (CB) als met een GES (CE)?
- 2. Is de ingangsimpedantie van een GBS zeer laag of zeer hoog?
- 3. Wat is het voordeel om gebruik te maken van een swamping-weerstand in een GBS?
- 4. Waarom heeft de GBS een hoger frequentieresponse dan zijn equivalente GES-versterker?



BJTs 8